


# CENTRAMATIC

## BALANCERS

**Centramatic Balancers** mount:

- Between the wheel and drum / hub on **INBOARD STEER** applications
- Between the wheels on **DUAL REAR** applications
- Outside of wheels on **OUTBOARD** applications



## INSTALLATION INSTRUCTIONS for OUTBOARD

### WARNING

Use of gloves is recommended. **Centramatic Balancers** are manufactured using thin steel, so holes and edges may be sharp and could cause injury.

### PRE-BALANCING

While pre-balancing is not required, it may be recommended by your dealer. A good computer balance can indicate a mis-mounted tyre, a defective tyre, bent wheels or other 'out-of-round' conditions. This leaves the full potential of the **Centramatic Balancer** to balance the drum, hub and quickly respond to changing conditions throughout the life of the tyre.

Do not 'strobe' or 'on-vehicle' balance while **Centramatic Balancers** are fitted. **Centramatic Balancers** do not work with this method - on jack stands, there is no deflection and the weights set up erratically under this condition.

### VIBRATION

If a vibration develops after installing **Centramatic Balancers**, this normally indicates a loose wheel bearing, or possibly a mechanical problem related to the suspension or undercarriage. **Centramatic Balancers** will not automatically balance the vehicle when such problems arise.

**1 Raise the vehicle or axle** so that the wheel may be safely removed using proper lifting / jacking techniques as recommended by the vehicle manufacturer.


**2 Before removing the wheel**, note the wheel / hub position by marking the wheel stud adjacent to valve stem, or similar method.

Now **check for out-of-round** wheel condition by placing a fixed object point on the ground a few mm gap from the tyre tread by turning the wheel slowly and noting if any change in the gap occurs. 2 - 3mm is acceptable; over 3mm is unacceptable. If unacceptable, one or more of 4 problems may exist. Check and correct as necessary:

**A Rim / hub pilot tolerance may be excessive.**

Remount wheel using centreing sleeves.

**B Rim not concentric.** Move fixed object point near rim and turn wheel noting if gap changes. Replace rim if necessary.



**C Tyre fitting not central on rim.** Check that tyre guide rib is same distance from rim around the entire circumference of rim. 2mm deviation is acceptable. If unacceptable, refit tyre to rim after turning 180°.

**D Out-of-round tyre.** Use tyre truer machine to correct tyre or replace tyre. **NOTE:** No amount of balancing can correct out-of-round wheel / tyre assembly. Tyres should be re-mounted / replaced or cut round with **Tyre Truer**.

**3 Remove old wheel weights** unless recently balanced. If balanced on-vehicle, replace wheel in same position as previously marked prior to removal. Remove any balancing material inside tyre.



**4 Remove 5 of the 10 wheel nuts** - removing every second nut - noting if nuts are flush-mount or spigot-type nuts.

**5 If spigot-type nuts**, ensure that the **Centramatic Balancer** has the correct hole size for spigot outer diameter, or stud diameter if non spigot-type nuts.


**6 Place outboard Balancer mounting brackets over the 5 studs without nuts** and ensure brackets are flush with outer flat face of rim. If spigot-type nuts, use 2 nuts to centralise **Balancer** - check **Balancer** doesn't touch any other part of rim, which could result in distortion of **Balancer** when nuts are tightened.

**7 Now, lightly seat all 5 nuts**, ensuring spigot-type nuts are all in position correctly in holes before using manufacturer's torque specifications and tightening sequence.

\*Outboard **Centramatic Balancers** are centred by the wheel studs / spigot nuts and, if not fitted centrally, will not work.



Flush mount nut



Spigot-type nut

ANY QUESTIONS CALL:

**1300 822 765**  
[www.centramatic.com.au](http://www.centramatic.com.au)

